

Touch Pad

Touch Pad is a pressure-sensitive pointing device. Touch pad is also known as track pad. It is also stationary device like trackball but it has no moving parts. It is a small, flat surface (or sensitive pad) over which a user slides fingertip to move the pointer on the screen.

Touch Pad also has one or two buttons. These buttons are located near the pad. These buttons work like mouse buttons. Touch Pad is normally used with laptops. Nowadays, it is also available as separate input device. It is fixed on separate keyboard.

