Device Drivers

Network interface cards come with drivers for different types of operating systems. A driver is the software that allows the operating system to communicate with the network interlace card. To ensure tile network interlace card performs optimally, the correct driver must be installed. If the operating system does not automatically install the correct driver after the network interface card has been added to the computer, you will have to install the driver manually.

